## FIRE TRUCK APPROACH DISTANCES WHEN DRAFTING

## Click HERE to download DWG

- Keep truck wheel loads at least **1** tank diameter away from the tank when on a non-concrete surface. Asphalt is not acceptable due to plastic deformation during hot weather.
- When the traffic surface is concrete and rated for H2O loads, the approach distance can be reduced to **1/2** the tank diameter.

